

Operating Instructions

Panasonic
CLOCK RADIO
Panasonic




FM/AM DIGITAL CLOCK RADIO

MODEL **RC-6003/RC-6003C**

Before operating this set, please read these instructions completely.

LOCATION OF CONTROLS



WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

ELECTRIC CLOCK OPERATION

- Plug the receiver's Power Cord into an AC electrical outlet (60 Hz, 120V), so your instrument is functioning as an electric clock. The Clock Dial will light up.

YOUR SOLID STATE CLOCK RADIO
MUST BE POWERED FROM
AN AC LINE ONLY.
NEVER CONNECT TO DC!

- Set Time Control...Turn clockwise to set the Clock Dial to the correct time. As this clock is a 24-hour system, be careful to set AM or PM on the Clock Dial correctly.

RADIO OPERATION

- Turn the Clock Selector Control to the ON position, but be sure the Sleep Control is set to 0.
- Band Selector Switch...Use this selector to choose the desired radio broadcast band, FM or AM.
- Tuning Control...Tune to your favorite station on FM (87.5~108 MHz) or AM (525~1605 kHz).
- Volume Control...Adjust to the desired sound level.

ANTENNAS

AM ANTENNA

This radio incorporates a sensitive built-in ferrite core antenna to assure excellent AM reception.

To improve reception of weak stations, re-position your radio cabinet until the loudest signal is attained.

FM ANTENNAS

BUILT-IN ANTENNA

This receiver has been connected to the built-in FM line antenna at the factory. Extend the power cord completely and change the direction of the power cord until optimum FM reception is obtained.

Your Panasonic dealer is most familiar with the type of reception in your particular area and if necessary, should be consulted for further information.

OPERATION AS A MUSICAL WAKE-UP ALARM

Your radio can be adjusted to turn on automatically.

- Preset the radio Tuning Control to the desired station, and adjust the Volume Control to the desired sound level.
- Turn the Set Alarm Control counter-clockwise to set the Alarm Dial to the desired "wake-up" time. As the Alarm Dial is a 24-hour system, be careful to set AM or PM on the Alarm Dial correctly.
- Preset the Clock Selector Control to AUTO position if you wish to awaken to the radio; preset to ALARM position if you wish to awaken to the buzzer alarm only.

Note: The radio (or alarm) will be shut off automatically after about 60 minutes. Once you set the radio (or alarm) to desired time, radio (or alarm) will be on every day at same hour, so it is not necessary to preset day after day. When you desire to turn off the radio (or alarm) before it automatically shuts off after about 60 minutes, turn the Clock Selector Control to OFF position.

OPERATION AS A GO-TO-SLEEP RADIO

Your radio can be adjusted to play and then turn off automatically after a preset interval up to 60 minutes.

- Adjust the Sleep Control to the period of time the radio is to play by turning the Sleep Control to any point between 0 and 60. If you set the Sleep Control midway between 0 and 60. The radio will automatically turn itself off after playing for about 30 minutes.
- Turn the Clock Selector Control to OFF position. (The Sleep Control now controls the power to the radio).

OPERATION AS A COMBINATION GO-TO-SLEEP/ MUSICAL WAKE-UP ALARM

Your radio can be adjusted to turn off automatically after a preset interval up to 60 minutes, and then turn on again at wake-up time.

- Preset the Sleep Control to a value between 0 and 60.
- Set the Alarm Dial to the desired "wake-up" time.
- Preset the Clock Selector Control to AUTO or ALARM position as desired.

HELPFUL HINTS

- Keep the radio away from heating appliances, and electrical noise generating devices such as fluorescent lamps and motors.
- The radio should not be directly exposed to sunlight and should be kept free from dust, moisture and vibration.
- To keep the cabinet clean, wipe off dust and stains with soft cloth moistened with mild soap and water.
DO NOT USE A SOLUTION CONTAINING BENZOL, PETROLEUM, ETC.

PRODUCT SERVICE

Should your Panasonic product ever require service, refer to the Directory of Authorized Servicenters enclosed with this radio or your franchised Panasonic dealer for detailed instructions.

WARRANTY

ONE YEAR PARTS AND LABOR SUBJECT TO THE TERMS OF THE WARRANTY. READ YOUR WARRANTY CARD COMPLETELY.

LOCATION OF SERIAL NUMBER...On the label pasted on the back of the cabinet.

MATSUSHITA ELECTRIC CORP. OF AMERICA

Pan-Am Bldg., 200 Park Ave. New York, N.Y. 10017

MATSUSHITA ELECTRIC OF HAWAII, INC.

320 Waiakamilo Road, Honolulu, Hawaii 96817

MATSUSHITA ELECTRIC OF CANADA LTD.

40 Ronson Drive, Rexdale, Ont.

RQX5688ZA F0674-0

Printed in Japan